

## 4.6 Enabling .NET Programmability Support in Microsoft Visio

Sometimes it is necessary to manually enable .NET programmability in Microsoft Visio so that WorkPlace Tech Editor and Monitor start normally. Use the instructions in this section to enable .NET programmability in Microsoft Visio.

### To enable .NET programmability support in Microsoft Visio

1. Open Windows Control Panel.
2. Click **Programs and Features**.




#### Note

The instructions outlined here describe the process for the Windows 7 operating system. If you are using a different version of Windows, start with the Control Panel, proceed to the appropriate dialog box where you can add or remove features of Microsoft Visio, and then enable .NET programmability support.

3. In the list of programs, select **Microsoft Office Visio** and then on the **File** menu, click **Change**.
4. In the **Change your Installation** dialog box, select **Add or Remove Features** and then click **Continue**.
5. On the **Installation Options** tab, expand **Microsoft Office** and then **Microsoft Office Visio**.

*Continued on next page*

6. Click **.NET Programmability Support**, select **Run from My Computer**, and then click **Continue**.



7. Windows reconfigures Microsoft Visio. When finished, click **Close**.

See related topics.

For more information, see section 5.2 “WorkPlace Tech Editor or Monitor Does Not Start ” on page 112.